



Installation Instructions for Mustang One-Piece Seat on 2010-2011 Honda VT1300 Stateline, Sabre, Interstate

Removal of stock seat:

1. Remove both side covers from motorcycle. They are a friction fit and are removed by pulling them from the frame starting at the bottom of each cover.



2. Locate and remove two Allen screws that hold the front of the seat in place, one on each side of the frame.



3. Locate and remove the single rear Allen screw at the back of the seat. It is hidden under the seat cover.
Then lift rear of seat up and pull whole seat back and off of motorcycle.



Installation Instructions for Mustang One-Piece Seat
on 2010-2011 Honda VT1300 Stateline, Sabre, Interstate

Installation of Mustang seat:

1. Slide seat's nose bracket into the opening behind the gas tank, just above the shock mount. Push seat forward until rear bracket aligns with hole in rear fender.



2. Use stock Allen bolt to secure rear of seat to fender.



Enjoy your new Mustang seat.

These steps are guidelines to help you install your new Mustang product. If you need further assistance please call us at 800-243-1392, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".
Ref: part #'s 76640, 76641, 76642, 79616, 79617