



MOUNTING SUGGESTIONS:

Harley-Davidson® FLRT Freewheeler™ 2015 One-piece Seat

Hardware:	Stock fender screw
Tools needed:	Phillips screwdriver



Removal of stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Mustang seat.
2. Slide the seat up and back to disengage the front bracket and remove the seat.

Installation of Mustang seat:

1. Engage the front seat bracket with the mount on the frame.
2. Align the rear tab with the fender hole.
3. Secure the rear bracket to the fender with the stock screw.
4. If equipped with a passenger backrest, use the knob in the back to hold the backrest in the desired vertical position.

Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 79592, 79593, 79594, 79595, 79596

**You are cordially invited to
— Tour the Mustang Factory —**

See how our craftspeople take pride in transforming raw materials into the world's highest quality, most comfortable handcrafted seats. Please contact Mustang for more information regarding tours of our historic Three Rivers, Massachusetts, facility (only 75 miles west of Boston; 150 miles northeast of New York City). Our two hour tours are by reservation only; we can accommodate groups from 2 to 24. We promise you will ride away with an entirely new awareness of what you put between you and your bike.