



PSR Frame Slider Instructions Ducati 626/1100/1100S

1. Remove the Top Engine Mount Bolt
2. Remove Nut, Slider Puck, 2" Spacer, Split Washer and Metal Washer from one side.
3. Remove Rubber Grommet from middle.
4. Push Rod through one side of the top engine mount, leaving one side of all the hardware intact.
5. Be sure to space evenly so that both sides have enough rod spacing so that the case will be protected.
6. Slide on metal washer, split washer and the 2" spacer. Tighten slider puck and metal nut back onto rod.
7. Apply Thread locking compound to each side.