

DUCATI MONSTER 821/1200 STEALTH FENDER ELIMINATOR KIT

- Remove seat and 2 bolts holding bottom body panel
- Remove 4 allen bolts holding stalks (picture 1)
- 3. Remove 4 hex bolts holding grab rails (picture 2)
- Let bottom body panel hang, exposing factory connectors (picture 3)
- Disconnect right / left blinker by cutting factory connectors off turn signals
- 6. Plug in new turn signals to OEM connectors
- 7. With supplied hardware, insert provided spacers and bolts into front







To inquire about custom parts installations

CONTACT US
INFO@NEWRAGECYCLES.COM | 914.339.2929



- holes on grab handles and tighten onto bike (picture 4)
- 8. With other spacers and bolts, insert into back holes on grab handles, slide new license plate in between, and tighten to bike (picture 5)
- Plug in license plate light and feed wire up underneath seat and tighten to plate bracket





To inquire about custom parts installations

CONTACT US
INFO@NEWRAGECYCLES.COM | 914.339.2929