

Kawasaki

Assembly Instructions

Description:	Smoked Wind Deflector	Model:	Vulcan 1700 Voyager
Part Number:	K99994-0176	Assembly Time:	15 min.

Before you begin installation, read through the installation instructions and check to be sure all parts are present.

If you are in doubt as to any part of the installation, please ask your authorized Kawasaki dealer to complete the installation. Please note that Kawasaki cannot assume any responsibility for damage resulting from incorrect installation.

Parts List				Tools Required:
Seq.	Part Number	Description	Qty.	Tool Description
1.		Deflector	1	4mm Hex Wrench

Installation Instructions

Deflector Installation Preparation

Parts Removal

- Remove the stock windshield.

NOTE:

O All hardware will be re-used.

Install Deflector

- Install deflector using stock trim piece, washers and screws.

NOTE:

O Tighten screws firmly, do not overtighten.

Maintenance

- To clean, pre-rinse screen with water to remove grit and soften dirt. Use mild soap, lots of warm water, and a clean soft cloth or sponge. Rinse well to remove all soap residue. Dry with a soft cloth. Washing may be followed by Kawasaki Plastic and Glass cleaner (K61080-002C), or other similar product.



Please check / adjust all screws in regular intervals.