## **Headlamp and Passing Lamps**

## PG-7 and PG-45 PG-TRI-7 PG-EXT-24 PG-EXT-24

## Note:

No loop cap needed. Headlight has loop cap built in.

Connect the ProGLOW™ wiring harness to Channel 1 of
the ProGLOW™ Bluetooth Controller. Note: If the Brake
Signal Sync is turned on in the App, The Channel 1 Override will need to be turned ON.

