

V3 FRAME SLIDER KIT 2.0


HONDA NC700 S/X

year of production: **ALL**


product code: SR116



Assembly position
(both sides)



Dimensions of the spacers



Assembly position (both sides)

Assembly instructions

1. Remove the original bolts indicated with the arrow on the assembly position scheme above.
 2. Replace the original bolt by the new mounting bolt (parts #7), the spacer 1 (parts #9) and adapter (part #6) according to the scheme on the right page. Put the steel adapters (parts #6 and #6A) in the right position according to the drawing on the right page.
 3. Assemble the slider, round cylindrical body, the bolt and the steel sleeve (parts #1, #2, #3 and #4) according to the drawing on the right page. Put them into the threaded hole in curved steel adapter (part #6A).
 4. Same operation is required in another side of the motorbike.
- We suggest to use the threadlocker (eg. Loctite) to make sure that the vibrations of the engine do not loosen the bolts.

Part #	Part name	Left side (as You sit on the motorbike)	Right side
1	Slider	1 pcs.	1 pcs.
2	Round cylindrical body	L = 40 mm	L = 40 mm
3	Steel sleeve	1 pcs.	1 pcs.
4	Allen bolt (8,8 class)	M10x60 mm	M10x 60 mm
5	Spacer	-	-
6	Adapter	Steel (flat #6) + Steel (Curved #6A)	Steel (flat #6) + Steel (Curved #6A)
7	Mounting bolt 1	M12x1,25x80 (Hex)	M12x1,25x60 (Hex)
8	Mounting bolt 2	Ø36 mm bracket	Ø36 mm bracket
9	Spacer 1	t = 20 mm, d = 35 mm	t = 20 mm, d = 35 mm
10	Spacer 2	-	-
11	Nut	M8, 2 pcs. to be put on the Ø36 mm bracket	M8, 2 pcs. to be put on the Ø36 mm bracket
12	Washer	M12, 1 pcs. to be put under the M12x1,25x80 Hex bolt's head	M12, 1 pcs. to be put under the M12x1,25x60 Hex bolt's head

Legal note. This product is a professional accessory to be used on the race track. Neither manufacturer, nor Seller take responsibility for any damages occurred despite of using protective accessories. For more information go to vortexracing.com